WINDOW GUIDE - GRØNJORDSKOLLEGIET







OPENING YOUR WINDOW

TURN THE HANDLE HORISONTALLY BEFORE OPENING THE WINDOW

LOCK POSITION OF WINDOW

WHEN YOUR WINDOW IS OPEN MORE THAN 20° YOU CAN TURN THE HANDLE VERTICALLY DOWN TO LOCK THE WINDOW IN PLACE











TILTING YOUR WINDOW

MAKE SURE THE WINDOW IS FULLY CLOSED
TURN THE HANDLE UPWARDS VERTICALLY BEFORE OPENING THE WINDOW

BE ATTENTIVE!

YOU SHOULD <u>ALWAYS</u> MAKE SURE TO <u>FULLY</u> CLOSE THE WINDOW BEFORE ATTEMPTING TO TILT, TURN OR CLOSE THE WINDOW

